

Instructions for:


Exhibitor Adjustable

STEP 1

Take the two upright poles (which telescope from 36" to 96") and insert into base. Tighten screw on underside of base. Do not overtighten.

STEP 2

Insert banner through top and bottom telescoping poles. Screw notched ends into upright poles at top and bottom. Do not overtighten.



STEP 3

The width and height of the unit is fully adjustable. Adjust counterclockwise to loosen and clockwise to tighten.

